Netatmo Smart Siren



The Smart Indoor Siren and the Smart Indoor Camera team up to keep your home extra secure

When an unknown face is detected by the Netatmo Smart Camera during your absence, the Siren immediately triggers a powerful 110 dB alarm to scare away the burglar.

The Netatmo Smart Camera uses face recognition and people detection to only trigger the Smart Siren when an intrusion occurs: no false alarms caused by a family member, a pet or a harmless movement.

Alarm arms and disarms itself automatically

Did you dash out of the house to catch your train and forget to switch on the alarm? No problem! The Netatmo Smart Alarm System arms and disarms itself automatically when you leave and return home.

You can relax: your smart equipment is programmed to help you! In addition, facial recognition prevents the Smart Indoor Siren from going off when your children come home but raises the alarm if it detects an intruder while you are away.

Easy to set up

Smart and straightforward - that's the thinking behind Netatmo products. Start by downloading the Netatmo Security app and follow the instructions. Simply place your Smart Indoor Siren on a shelf or table or fix it to the wall next to your Indoor Camera.

The Netatmo Smart Indoor Siren can run on battery power or plugged in - it's up to you.

Pre-recorded noises make it sound like there's someone home

The wireless Smart Siren comes with a variety of pre-recorded sounds such as dog barks and other home noises.

You can choose to play them in order to simulate presence and thus deter burglars from entering your home.

Your Smart Indoor Siren tells you when someone tries to disable it

The Netatmo Smart Indoor Siren alerts you when someone tries to disable it. You receive an instant notification on your smartphone while your Indoor Siren sounds its 110-decibel alarm. Deter intruders and prevent break-ins effortlessly.

Set off the alarm from your smartphone, wherever you are

Your Smart Indoor Siren is ready for anything. Wherever you are, in an emergency you can trigger it remotely via your smartphone. If you suspect a break-in while you're at the end of the garden or visiting a neighbour, simply sound the 100-decibel Netatmo Smart Indoor Siren to scare the intruder away.

For an extra layer of security

Add the Indoor Siren to your Netatmo Smart Indoor Camera for a complete security system that protects your home. The Siren only works with the Indoor Camera, sold separately.

Specifications Netatmo Smart Indoor Siren

Product description

110 dB alarm, pre-recorded sounds to simulate presence, vibration sensor for tamper detection

Product size

130 mm (diameter) x 35 mm (depth) / 5.1 in (diameter) x 1.4 in (depth)

Power

Battery-operated or hardwired through microUSB cable (not included)

Pack contents

- 1 Smart Indoor Siren
- 4 AA batteries with 2-year lifespan (already inserted in the product)
- 1 mounting kit

Requirements

The Smart Indoor Siren only works with the Netatmo Smart Indoor Camera, sold separately. It needs to be installed indoors, in the same room as the Camera. Maximum 1 Siren per Camera

Connectivity specifications

Wireless connection with the Smart Indoor Camera via Bluetooth Low Energy (BLE)

Free app

- No subscription fee
- App available on the App Store / Google Play
- Free access to your dashboard online

App compatibility

- iOS 10 minimum required
- Android 5.0 minimum required
- PC & Mac through the Webapp

Browser support

Webapp available for the two latest versions of: Chrome, Safari, Firefox, Internet Explorer